

Climber Error code

Code	Meaning	Solution
1	Controller error	Stop drive
2	Motor hall error	Stop drive
3	Battery failure	
4	Battery low-voltage	Stop drive, stop braking force by half
5	Battery over-voltage	Stop drive, stop brakes
6	Brake handle failure	Stop drive, stop brakes
7	Throttle handle failure	Send empty throttle, brake force effective
8	/	/
9	Controller data not received by dashboard	Stop drive
10	Controller doesn't receive dashboard data	Stop drive
11	MOS over temperature	Depending on the temperature, primary protection reduce drive, secondary protection stop drive
12	Motor over temperature	Depending on the temperature, primary protection reduce drive, secondary protection stop drive
13	/	/